

# Alligare IMOX® Water Sampling Instructions

#### SAMPLE COLLECTION

- 1. It is essential to avoid contamination of water samples during the collection process. IMOX is measured in parts per billion (ppb) and, trace amounts of Alligare IMOX® or other imazamox- containing products from equipment, clothing, boats or vehicles can easily contaminate the water sample. TAKE EXTRA PRECAUTIONS TO AVOID CONTAMINATION AND EXPOSURE TO SUNLIGHT.
- 2. Complete the Alligare Sample Submission Form to include the rate product was applied.
- 3. Draw a map of the water body and number the sample locations on the map where water samples will be collected. Number the empty sample bottles with the enclosed marker.
- 4. At each collection site, submerge the 225 ml brown sample bottle upside down approximately 18-20 inches below the surface of the water. Turn the bottle upright and slowly bring the bottle to within 2-4 inches of the surface, allowing it to fill.
- 5. Remove the bottle from water. Dispense some water from the bottle to leave space at the top ¾" of the bottle for expansion when freezing. Remove bottle from the water and place in a cooler. Keep the cooler lid closed to avoid exposure to sunlight.

## **SAMPLE HANDLING**

- 1. Leave space at the top of each bottle to allow for expansion during freezing. Tape bottle caps securely to ensure they do not leak.
- 2. Freeze samples overnight if possible or store in a refrigerator overnight prior to shipping.
- 3. Avoid exposing sample bottles to sunlight or heat.

#### **SHIPPING**

- 1. Place frozen samples in sealable plastic bags prior to shipping to ensure protection from condensation.
- 2. Ship frozen samples overnight in shipping container. If samples are not frozen, ship the samples with an ice pack. Do not ship samples in loose ice.
- 3. Do not ship samples over a weekend. Samples collected on a Friday should be frozen and shipped on Monday for overnight delivery. IT IS MOST PREFERRABLE TO SHIP ONLY ON MONDAYS, TUESDAYS OR WEDNESDAYS.
- 4. Ship SamplesTo: Waters Agricultural Laboratories, Inc.

Attn: Jessica Moss

257 Newton Road Camilla, GA 31730

(229) 336-7216

# **COSTS**

- 1. Cost per sample \$125
- 2. Return Overnight Shipping Cost (label included in box) \$12.50. If you choose to cover this cost yourself, please provide your own overnight label and discard the one in the box.
- 3. Alligare, LLC will invoice you after samples results are returned to you. The unused water in each sample bottle will be saved for 2-3 weeks in the case a re-test is warranted.

## **QUESTIONS**

1. Contact Dave Blodget: 661-599-3231 or <a href="mailto:dave.blodget@alligare.com">dave.blodget@alligare.com</a>